

MF-61 PARTS

- 16 — [Screw]
- 15 — [Washer]

- 15 — [Washer]

1

2

3

4

8

9

10

11

5

15

22

O

[Washer]

O

[Washer]

O

[Washer]

O

[Washer]

6

7

12

13

21

14

15

16

18

17

20

19

19

19

